JC371 COMMAND MANUAL

DMS Events & ADAS Events

1. DMS Screen Position

Command	Description
DMSSP,DMS,30,2,0#	DMS screen — Full image
DMSSP,DMS,30,2,1#	DMS screen — Left side
DMSSP,DMS,30,2,2#	DMS screen — Middle side
DMSSP,DMS,30,2,3#	DMS screen — Right side

2. DMS Events — Driver Monitoring

Command	Description
EVENTSET,ACEA,2,3#	Eye close
EVENTSET,ADDW,2,3#	Yawn
EVENTSET,ADW,2,5#	Distraction
EVENTSET,ASW,2,5#	Smoking
EVENTSET,ACPW,2,5#	Cell phone use
EVENTSET,ASS,2,5#	Sunglasses
EVENTSET,ANDD,2,5#	No driver detected
EVENTALERT,ACEA,0,120,5#	Enable Driver Fatigue Voice Alert

3. ADAS Events — Road & Vehicle Safety

Command	Description
EVENTSET,APCW,1200#	Pedestrian detection
EVENTSET,AHMW,1200#	Front vehicle close
EVENTSET,AFCW,1200#	Forward collision warning

4. Driving Behaviour Events

Command	Description
EVENTSET,AHADU,3.5#	Harsh acceleration — threshold 3.5
EVENTSET,AHBDU,-4.5#	Harsh deceleration — threshold -4.5
EVENTSET,AHTDU,4.0,45#	Harsh turning — threshold 4.0, angle 45

Note: *Commands and descriptions are formatted from the information provided. Confirm parameter definitions and supported values against the JC371 firmware/manual before applying commands to active devices.*